

# Bosch Video Management System 7.5

www.boschsecurity.com



**BOSCH**  
Invented for life



- ▶ Maximum resilience to ensure continuous operation.
- ▶ Up to 2000 cameras with a single recording server mean high savings.
- ▶ Smart automatic stream switching for live viewing.
- ▶ Best integration with Bosch video hardware.
- ▶ Encrypted communication to cameras.

The Bosch Video Management System is a unique enterprise IP video security solution that provides seamless management of digital video, audio, and data across any IP network. It provides the best VMS to go with Bosch CCTV devices, leveraging the unique capabilities of Bosch cameras and recording solutions. It nevertheless offers interfaces and standards to integrate other systems and manufacturers. The system is equipped with a unique embedded resilience.

It keeps operations up and running even when both, Management and Recording Servers fail. On edge intelligent Video Analyses and the unmatched recording technology managing up to 2000 cameras with a single server dramatically reduces the total cost of ownership.

The Bosch Video Management System allows a very flexible system design:

- Professional: Single Management Server System 1 to 2000 cameras out of the box. Only this system supports Bosch VMS-BIS Connectivity.
- Enterprise System: Supporting multi Management Server requirements for Metro, Airport and other large industrial facilities across different time zones. Supports controlled monitoring across different legal entities. Monitoring of up to 10,000 cameras across

10 subsystems per user group resulting in 200,000 cameras in total.

Up to 30 subsystems per user group for <100 cameras per subsystem, allowing each operator to access events, alarms, live and playback from up to 30 Management Server computers simultaneously.

- Maximum 2000 ONVIF cameras per Management Server.
- Access to live including PTZ control and recorded video of up to 9999 sites with Bosch DVR recorders, DIVAR IP 3000 / 7000 and single Management Server systems.

The Bosch Video Management System is installed on a Microsoft Windows Operating System.

We recommend using Bosch Workstations and Servers. They are fully tested and optimized for Bosch Video Management System.

In addition to the Bosch ST standard terms and conditions of sale, the Bosch Software Maintenance Agreement is a great option to keep the VMS always up to date.

The Bosch Software Maintenance Agreement is available in the product catalog.

## System overview

### Software components

- Management Server software provides management, monitoring, and control of the entire system. One single Management Server manages up to 2000 Cameras/encoders.
- Enterprise Management Server provides access to multiple Management Servers.
- Video Recording Manager (VRM) provides recording and playback management of video, audio, and data. One single VRM manages up to 2000 cameras/encoders (including up to 2000 ONVIF cameras).
- Configuration Client software provides the straight forward user interface for system configuration and management.
- Config Wizard software provides easy and fast setup of a small recording system when using the Bosch VMS Appliance.
- Bosch VMS Appliance: DIVAR IP 3000/7000 is a simple and reliable all-in-one recording, viewing, and management solution for network surveillance systems with 32 channels pre-licensed.
- Operator Client software provides the ergonomic and intuitive user interface for system monitoring and operation.
- Mobile Video Service provides a transcoding service. It transcodes the live and recorded video stream from a configured camera according to the available network bandwidth. This service enables video clients to view high-quality images via low bandwidth.
- Mobile App (iPhone or iPad): Access live and playback video from remote in single or quad-view. Alert and share live video from mobile camera with other security staff with a single click. App available in AppStore.
- Web Client: Access live and playback video from remote in single or quad-view. Search for text data and trigger export of videos on Management Server.
- Bosch Video Streaming Gateway: Bosch cameras, ONVIF cameras, JPEG cameras, RTSP encoders.

Bosch Video Recording Manager (VRM) provides a Distributed Network Video Recorder solution, eliminating the need for dedicated NVRs. The usage of multiple client Workstations offers great scalability.

### Included parts

Bosch VMS is delivered electronically via download of the Setup in the Product Catalog.

The Setup contains the following items:

- Installation program that can selectively install all components (Management Server, Video Recording Manager, Configuration Client, Operator Client, Video Streaming Gateway, Mobile Video Service, Bosch VMS SDK, Cameo SDK) in all supported languages.
  - Configuration Manual (PDF format)
  - Operation Manual (PDF format)
- Quick Installation Guide (PDF format) in English, French, German, Simplified Chinese and Spanish.

Licenses are provided as eLicenses via email.

## Functions

### Embedded Resilience

- An Offline Client ensures continuous operation for live, playback and export while Management Server is disconnected.

### Video Recording Manager (VRM)

VRM provides load balancing and failover for the iSCSI Storage System and makes it easy to add additional iSCSI Storage Systems later on. VRM introduces the concept of a storage virtualization layer. This abstraction layer enables VRM to manage all of the individual disk arrays in the entire system as various “virtual” pools of storage, which are intelligently allocated as needed.

A storage pool is a container for one or more iSCSI storage systems that share the same load balancing properties.

Dual / failover recording:

- A Primary VRM manages the normal recording of the cameras of your system. You use a Secondary VRM to achieve dual recording of your cameras. Dual recording allows you to record video data from the same camera to different locations. A Secondary VRM can manage the secondary recording for multiple Primary VRMs. A Failover VRM is used for continuing the recording of a failed Primary VRM or a failed Secondary VRM computer.

Bosch VMS furthermore supports Live and Playback of the following recording engines:

- DIVAR IP series, Local Storage, Direct iSCSI recording; Bosch Recording Station (BRS), Video Streaming Gateway (VSG).

For legacy purposes the following recording engines are supported: DVR, DiBos, VIDOS (Live only).

### Cameras

- Supports Bosch UHD and panoramic cameras, MPEG-4 & H.264 encoders, MPEG-4 & H.264 IP cameras, and IP AutoDome cameras in SD & HD format.
- Supported HD resolutions: 720p and 1080p, 5, 8 and 12 Megapixel.
- Intelligent Video Analytics and Forensic Search.
- Video-based fire detection.
- Automated Network Replenishment (ANR).
- Region of Interest (ROI).
- Intelligent tracking .
- Quality settings attuned to each camera type. Refer to data sheets of the cameras for further details.
- Support of 3rd party cameras via RTSP, JPEG, or ONVIF Profile S. The list of supported 3<sup>rd</sup> party cameras is published on the Bosch Integration Partner Program website.

### Deployment

- Updates of Operator Client and Configuration Client automatically deployed from Management Server
- One-click hotfix deployment

- Internet Information Service is configured automatically for use with Mobile Video Service, enter the desired number of VSG instances, perform an update installation with a very few clicks.

### Configuration

- Generic camera connection.  
Bosch VMS retrieves the values of currently known features on connection to unknown Bosch IP cameras/encoders. You can add a camera/encoder of an unknown device type as a generic device with a limited feature set.  
Valid for firmware 5.70 or later.
- Scan of IP devices.
- IP address assignment of IP devices.
- Configurable Logical Tree.
- Device states indicated by icons, including network connection loss, video loss, and camera de-adjustment.
- Batch firmware updates of IP devices.

### Scheduling

- Up to 10 Recording Schedules with Holidays and Exception Days
- Task Schedules with Holidays, Exception Days, and recurring schedule support
- Per camera settings for minimum and maximum recording times
- Per camera, per recording schedule frame rate and quality settings for live, normal recording, motion recording, and alarm recording

### Event handling

- Compound events (combining events with Boolean logic)
- Event duplication allowing separate handling
- Event assignment to user groups
- Schedule dependent event logging
- Schedule dependent event-triggered Command Script invocation
- 4 configurable user-events (can be triggered via menu command)
- Mapping of ONVIF events to Bosch VMS events. ONVIF events can then trigger Bosch VMS alarms and recording

### Alarm configuration

- Schedule dependent alarm generation.
- Alarms can trigger alarm-mode recording for any cameras.
- 100 alarm priorities can be defined.
- Occurrence of text data can trigger alarm recording.

### Sequences

- Pre-configured camera sequences with 25 cameras with each up to 100 steps with individual dwell times.
- “Automatic Sequences” created by multiple selection and drag to Image panes.

### User Management

- LDAP compatible for integration with user management systems such as Microsoft Active Directory
- Access to system resources individually controlled per user group

- Logical Tree customized per user group – users only see devices for which they have access
- User group rights for protecting, deleting, exporting, and printing video
- User group rights for Logbook access
- User group priority assignment for PTZ control and Allegiant camera access
- Individual per-camera privileges assignable per user group for live access, playback, audio, text data display, PTZ control
- Dual-authorization logon – special privileges and priorities granted when two users log on together

### Efficient operation

Bosch VMS puts a strong emphasis to efficient operation, which consists of several disciplines:

#### Equipment:

- Workstations are protected by an Inactivity logoff during the absence of the operator.
- Up to 4 PC monitors supported per Workstation. Arbitrary number of Bosch Monitor Walls or a Barco Monitor Wall (Transform N-series) may be used in addition.
- KBD-Universal XF keyboard supported, connected to Workstation via USB interface.
- KBD-Universal XF keyboard supports Enterprise System (select the desired Management Server).
- Bosch IntuiKey keyboard supported, connected to either Workstation or IP decoder.
- Bosch IntuiKey keyboard supports Enterprise System (select the desired Management Server).

#### Intuitive operation:

- A unique flexible Image window (patent pending) allows any combination of video window sizes and layouts without the need of pre-configured layouts
- Any live Image pane can be switched to instant playback (not valid for transcoded streams)
- Multiple instant playback Image panes
- Image panes can display live video, instant playback video, text documents, maps, or web pages
- Enhanced map features: Device states indicated on icons; special state events (for example motion alarm) can be highlighted by defined colors or blinking; thumbnail of camera appears on mouse over; alarms of devices can be accepted and presets can be accessed via context menu
- Camera selection by double-click or drag and drop from site maps, Logical Tree, or Favorites Tree
- Decoders can be organized in Monitor Walls from within Operator Client Monitor Walls can be controlled without connection to Management Server
- Control of analog monitors connected to decoders via drag and drop
- Automatic stream switching depending on Image pane size and digital zoom level in Live Mode

#### Efficient surveillance:

- Favorites tree can be individually configured per user.
- Call up Favorites with a click. Include complete views with Image pane layouts and camera assignments.
- Intelligent tracking enables the camera to assist the operator by following an automatically or manually selected object (PTZ camera or fixed cameras).

- Zoomable sitemaps with links, devices, sequences, and Command Scripts provide excellent overview.
- Automatic map positioning of a camera in a map when this camera is selected.
- Two audio listening options – selected channel only, or multiple simultaneous channels.
- Audio Intercom functionality.
- When operating from a remote access, the operator can retrieve Live and Playback via low bandwidth using transcoded video or TCP for reliable connection (Live Mode). Using the Region of Interest feature saves network bandwidth when zooming into a section of the camera image.

#### Efficient response:

- Intelligent Video Analytics is the state-of-the-art method that reliably detects, tracks, and analyzes moving objects while suppressing unwanted alarms from spurious sources in the image
- Priority threshold defined for each operator group for escalation management
- Selective auto-popup on alarm
- Alarms displayed in separate alarm window
- Up to 5 Image panes per alarm with live or playback video, sitemaps, documents, or web pages displayed in an “alarm row”, with highest priority alarms on top
- Audio file per alarm
- Workflow with user instructions and user comments, optionally forced before clearing
- Email or SMS notification on alarm
- Alarm display on Monitor Wall
- Alarm auto clear options either time or state dependent

#### Efficient investigation:

- Forensic Search allows the usage of Intelligent Video Analysis (IVA) algorithms on the recorded video
- Motion search in recordings allows easy locating of changes in selected areas
- Sophisticated multi-camera Timeline allows easy, graphical searching of recorded video
- Bookmarks in Live and Playback Mode for easy investigation and export of recordings
- Selected clips can be exported to DVD, network drives, or USB sticks with a few mouse clicks
- The operator can search for text data to quickly find the corresponding recordings
- Text data is delivered by systems like foyer card readers, automatic teller machines, point of sales, petrol stations or Automatic Number Plate Recognition  
Text data contains textual transaction data like account numbers and bank routing codes. The text data is stored within the Logbook as well as in the recordings

#### System Monitoring

- System-wide health monitoring, including Bosch cameras, computers, and software.
- Network equipment and other third-party devices monitored with SNMP.
- SNMP monitoring on the Management Server computer provides monitoring information to other Management Systems.

#### Customization and Interfacing

- Server SDK controls and monitors Bosch VMS Management Server by scripts and external applications.
- Client SDK controls and monitors Bosch VMS Operator Client by external applications and scripts (part of the related server configuration).
- Client Enterprise SDK controls and monitors Bosch VMS Operator Client of an Enterprise System by external applications.
- Cameo SDK easily embeds the content of the Bosch VMS Image pane into clients of 3rd party Physical Security Information Management (PSIM) and other management systems.  
For each Cameo SDK instance you need a Workstation license.
- Custom Command Scripts can control all system functionality.
- Powerful built in Command Script editor supports C# and Visual Basic .Net.
- External software can trigger events and send text data via virtual inputs.
- Any .Net programming language (for example C#) can be used to interface Bosch VMS functionalities.
- Other systems can control a virtual matrix with Allegiant CCL commands that can be sent via RS232.
- Compatible with Advantech ADAM-6000 series Digital Input / Output modules.
- Compatible with Bosch Building Integration System.
- Compatible with UL intrusion panels from Bosch.

#### Technical specifications

##### System Specifications

Maximum number of workstations simultaneously viewing the same camera	Multicast: 100 Unicast: 5
Supported GUI languages	English, German, Dutch, Italian, Portuguese, French, Spanish, Simplified Chinese, Traditional Chinese, Russian, Hungarian, Japanese, Czech, Danish, Finnish, Greek, Norwegian, Polish, Swedish, Thai, Turkish, Korean, Arabic, and Vietnamese
Anti-Virus software must not perform a full-scan. Performance may decrease depending on configuration.	
Event reaction time	<1 second, assuming sufficient network bandwidth
Alarm reaction time (incl. 1 live Image pane, 1 instant playback Image pane and 1 map Image pane):	Maximum 2 seconds, assuming sufficient network bandwidth

Text data	Restrictions for text data written into the Logbook (this applies, if entry is stored only in Logbook, not in recordings): 10*Virtual Input (VI) with length 300 = 3000 characters: 109 items/sec (average) 10 * VI data field with length 800 = 8000 characters: 22 items/sec (average) 10 * VI data field with length 30 = 300 characters: 500 items/sec (average) (item = data input event) Restrictions for text data written into recordings: Bosch VMS can only process up to 3200 Bytes (corresponds to about 3200 English characters in Unicode) per event.
Bandwidth requirements for LAN	Min. 1 Gbps for connections between: Operator Client and Management Server Operator Client and VRM/DiBos Management Server and NVR/VRM/DiBos
Bandwidth requirements for remote access	>= 300kbps
Hardware transcoder	Hardware transcoder VIP-XTCXF-INT or VJT-XTCXF must be configured in VRM, refer to VRM documentation. Hardware transcoding only applicable for VRM connected BVIP cameras. For transcoding live streams it is not required that the respective camera is recording.
Required open ports	See Online Help or Manual for Configuration Client, chapter on used ports.

### Management Server Specifications

Maximum number of sustained events	For highest performance server: 500 events/s with Logbook 1000 events/s without Logbook 5000 events/s at peaks (within 60 minutes) with Logbook 500 events/s from ONVIF cameras
Logbook	Supported by SQL Server 2014 Express (64-bit version) 4 GB Logbook size
Maximum number of Task Schedules	200

### Management Server Specifications for Redundancy

#### Management Server Redundancy (VMware)

Available with VMware HA. Please contact Bosch Design Engineer for redundancy solutions.

The following software versions are used:

- ESXi Server 5.1.0 U1 build 1065491
- vCenter Server 5.1.0 U1 build 1064983

Required hardware

- 2x HP ProLiant DL380 PCs with 8 GB RAM and 1x 4-port NIC (one DLxxx for each ESXi server).
- 1x HP ProLiant DL380 PC with 8 GB RAM (for Control computer with monitoring) Not necessary if Control computer is installed on ESXi server as virtual machine. Note: For configuration, only a workstation is required.
- 1x Bosch DSA E-Series.

For use with VMware you must install the default NetApp firmware on a DSA E-Series device. The firmware and the manual are available in the Product Catalog of Bosch VMS (**Software & Support**).

Required VMware licenses/Windows licenses

- 1x VCS-FND-C VMware vCenter Server 5 Foundation for vSphere up to maximum 3 hosts. SNS is required.
- 1x VCS-FND-G-SSS-C Basic Support/Subscription for vCenter Server 5 Foundation for vSphere for 1 year.
- 2x VS4-ADV-C VMware vSphere 5 Advanced for 1 processor (maximum 12 cores per processor). SNS is required. Included: vShield Zones, Data Recovery, Fault Tolerance, Hot Add, vMotion, Thin Provisioning, High Availability, Update Manager, VCB / Storage APIs, VC Agent, 4-way vSMP, VMware ESXi or

	<p>VMware ESX, 12 Physical Cores/CPU, 256GB Physical Memory.</p> <ul style="list-style-type: none"> <li>2x VS4-ADV-G-SSS-C Basic Support/ Subscription for VMware vSphere. Advanced for 1 processor for 1 year.</li> </ul> <p>If current hardware is used, the following licenses must be ordered additionally:</p> <ul style="list-style-type: none"> <li>1x Windows license for: Windows Server 2008 R2 (64 Bit) for control computer and ESXi server.</li> </ul> <p>3x licenses for 2nd CPU</p>
Management Server Disaster Recovery (Hyper-V Replica)	<p>Hyper-V from Microsoft OS requirement: Windows Server 2012 SR2 (64-bit)</p> <p>Minimum hardware requirements: 2 HP ProLiant DL380 PCs with 16 GB RAM and 1x 4-port NIC, 200 GB hard disk</p>
Management Server High Availability (Hyper-V Failover Cluster and Starwind)	<p>Hyper-V from Microsoft; OS requirement: Windows Server 2012 SR2 (64-bit) with Domain Controller for HA</p> <p>Minimum hardware requirements: 2 HP ProLiant DL380 PCs with 16 GB RAM and 1x 4-port NIC</p> <p>Shared storage for HA: Tested with NetApp DSA E-Series 2600 with 2 controllers</p>

### VRM Specifications

Version	3.60 Previous versions are not supported.
Maximum count of VRM servers per Management Server	125 (maximum 2000 Cameras in total)
Maximum data rate per iSCSI	Please contact Bosch Design Engineer for iSCSI storage solutions.
Max. number of playback sessions	64

### Minimum Client Workstation PC Requirements

Operating System	Windows 8.1 (64-bit, Professional or Enterprise) Windows 10 (64-bit, Professional or Enterprise, patched with Anniversary
------------------	--

	Update) We recommend installing Internet Explorer 11.
CPU	Intel Core i7 4770 3.4 GHz (up to 3.9 GHz)
RAM	Minimum 8 GB
Free disk space	Minimum 3 GB for Single Site Systems Minimum 5 GB for Enterprise Systems We recommend having minimum 15% free disk space.
Network card	1000Base-T
Display Resolution	Minimum per monitor 1024x768 1280x1024 or higher recommended
Recommended Graphic Cards	MHW-AWGC-K2200 MHW-AWGC-K620 MHW-AWGC-K4200 MHW-AWGC-K5200

### Graphic Cards Specifications

The Application Guide “Display performance indication” contains the following detailed information:

- Maximum number of Image panes
- CPU load for various workstations or servers and their graphic cards

### Minimum Management Server, Mobile Video Service and Configuration Client PC Requirements

Operating System	Windows 2012 Server R2 (64-bit) or Windows 2008 Server R2 SP1 (64-bit) required for > 500 cameras Windows 8.1 (64-bit) required for Management Server, Configuration Client and Operator Client on the same computer, and maximum 500 IP cameras/encoders We recommend installing Internet Explorer 11.
CPU	Intel Core i7 4770 3.4 GHz (up to 3.9 GHz)
RAM	Minimum 8 GB
Free disk space	Minimum 15 GB We recommend having minimum 15% free disk space.
Network card	1000Base-T
Display Resolution	1280 x 1024

**Minimum VRM Server PC Requirements**

Operating System	Windows Server 2008 R2 (Standard Edition, 64-bit), Windows Storage Server 2008 R2 (Standard Edition, 64-bit), Windows 7 Ultimate, Professional (SP1, 32-bit, 64-bit), Windows Server 2012R2, Windows Storage Server 2012R2
CPU	1x or 2x Quad-Core Intel Xeon Processor E5606 (2.13 GHz, 8 MB L3 cache) or faster
RAM	Minimum 4 GB
Free disk space	1000 MB We recommend having minimum 15% free disk space.
Network card	1 Gbps
Display Resolution	1024x768 or higher

**Mobile App / Web Client Requirements**

Link to App Store	<a href="http://www.boschsecurity.com/MobileVideoService">www.boschsecurity.com/MobileVideoService</a>
Maximum number of Mobile Video Service instances per Management Server	5
Number of simultaneous connections per Mobile Video Service (1 mobile device consumes 1 connection, each stream consumes another connection)	up to 20
Supported cameras	IP cameras with H.264 or H.263 support that are controlled by Bosch VMS (not controlled by VIDOS) ONVIF cameras BRS/DiBos/DVR cameras
iOS Version for iPhone/iPad	7.1 / 8.3 / 9.0.2 / 9.3.5 / 10.0.1
Hardware version iPad	iPad, iPad 2, iPad 3 <sup>rd</sup> generation
Hardware version iPhone	iPhone 4, iPhone 4S, iPhone 5C
Browser (Web Client)	Internet Explorer 11.0.96, Firefox 45.0.2, Chrome 50.0.2661

**Device Compatibility**

Intrusion panels from Bosch	For use with Bosch VMS, the <b>Automation Device</b> in the intrusion panels must be configured as <b>Mode 2</b> . <b>G-Series US1A:</b> B9512G (required firmware version: 3.03.14)
-----------------------------	--

B8512G (required firmware version: 3.03.14)

**B-Series US1B:**

B5512 (required firmware version: 3.03.14)

B4512 (required firmware version: 3.03.14)

B3512 (required firmware version: 3.03.14)

**GV4 panels (not supported if Microsoft Windows patch 3155464 has been applied to the system):**

D9412GV4 (required firmware version: 2.03.018)

D7412GV4 (required firmware version: 2.03.018)

Barco Monitor Wall Transform N Series	Barco RCPPlus-Agent 0.9.0.7
Analog Matrix Switch	Bosch Allegiant series, firmware 8.75 or later and Master Control Software version 2.94
Bosch POS/ATM Bridge	Version 1.10.00.12(63029)/2010-9-10
CCTV Keyboard	KBD-Universal XF keyboard (USB keyboard) Bosch IntuiKey keyboard, firmware version 1.96
Digital I/O	Digital I/O Advantech ADAM-6050, ADAM-6052, ADAM-6060, ADAM-6066
Digital Video Recorder	DVR 431, 440, 451, 480, 630, 650, 670, 700 series (maximum 50 managed DVRs per Management Server) Bosch Recording Station 8.10, 8.11 DIVAR AN 3000 / 5000 DiBos, firmware version 8.7 Maximum 100 BRS/DiBos recorders per Management Server
USB to Serial adapter	Belkin serial adapter cable F5U103vea
Ethernet to Serial adapter	Comtrol DeviceMaster RTS 4-Port

BVIP Devices	DINION IP starlight 6000 HD, DINION IP starlight 7000 HD, FLEXIDOME IP starlight 6000 VR, and FLEXIDOME IP starlight 7000 VR FLEXIDOME IP panoramic 5000/7000 FLEXIDOME and DINION 2000/4000/5000/7000/8000/9000 cameras series AUTODOME IP 7000/5000/4000 EXTEGRA IP 9000; MIC 7000 with VIDEOJET 7000 (supporting alarm inputs, and outputs, audio, washer relay, local recording and playback); MIC 612/550 MIC 550, 612, MIC7000 cameras with VIDEOJET connect 7000 (supporting alarm inputs and outputs, audio, washer relay, local recording, and playback) H.264 Series encoders and cameras MPEG-4, H.264 Main Profile, H.264 Baseline Plus are supported (H.264 Baseline and MPEG-2 are not supported) VIP-X Series encoders and cameras Decoder: VIDEOJET decoder 3000/7000 VIDEOJET decoder 8000 (supports 4K ultra HD cameras on Monitor Wall) VIP XD HD VIP XD
ONVIF cameras	Maximum 2000 ONVIF cameras Supported cameras are listed on the Bosch Integration Partner Program website. For non-listed cameras refer to MBV-3RD PRTY
Unmanaged sites	Maximum 9999 unmanaged sites Supported unmanaged devices: Bosch VMS, DIVAR IP 3000/7000, DVR 431, 440, 451, 480, 630, 650, 670, 700 series, DIVAR AN 3000, DIVAR AN 5000 Maximum 5 DVR/DIVAR AN devices per site
Connectivity with Building Integration System	Version 4.2 / 4.3
Foyer Card Readers	Maximum 2 readers per Management Server are supported. MINITER 485 is supported.
DTP 3N Box	Allows for connecting maximum 4 ATM devices to your Management Server.
Audio devices	Supported audio formats: <ul style="list-style-type: none"> <li>G.711</li> <li>L16</li> </ul>

### Remote Access

Direct iSCSI and encoder replay are not supported.

VRM	Live, playback, PTZ control
ONVIF	Live, playback, PTZ control (all via VSG)
Local Storage	Live, PTZ control

Live Only	Live, PTZ control
BRS/DiBos	Not possible
DVR	Live, playback, PTZ control

### Ordering information

#### BVMS Demo 7.5

Demo license for 3 cameras, 2 workstations, 2 CCTV keyboards, 2 DVRs.

Order number **MBV-BDEM-75**

#### BVMS Lite-32 7.5

Lite license for 32 Cameras, 2 workstations, 1 CCTV Keyboard, 1 Mobile Video Service.

Order number **MBV-BLIT32-75**

#### BVMS Lite-64 7.5

Lite license for 64 cameras, 4 workstations, 2 CCTV Keyboards, 1 Mobile Video Service.

Order number **MBV-BLIT64-75**

#### BVMS Professional Edition 7.5

Base license for Professional Edition. 8 cameras; 2 workstations; 1 CCTV keyboard; 1 DVR. All MBV-X\* and MBV-F\* options are only available with Base license.

Order number **MBV-BPRO-75**

#### BVMS Enterprise Edition 7.5

Base license for Enterprise System. 2 Management Server subsystems (1 required for Enterprise Management); 8 cameras; 2 workstations; 1 CCTV keyboard; 1 DVR. All MBV-X\* and MBV-F\* options are only available with Base license.

Order number **MBV-BENT-75**

#### BVMS Channel (cam/dec) Expansion V7.5

Expansion license for 1 encoder/decoder channel. Order the exact number required.

Order number **MBV-XCHAN-75**

#### BVMS Workstation Expansion V7.5

Expansion license for 1 workstation (each extra workstation requires 1 license).

Order number **MBV-XWST-75**

#### BVMS DVR Expansion V7.5

Expansion license for 1 DVR. Order the exact number required.

Order number **MBV-XDVR-75**

#### BVMS CCTV Keyboard Expansion V7.5

Expansion license for 1 CCTV keyboard. Order the exact number required.

Order number **MBV-XKBD-75**

#### BVMS Enterprise Subsystem V7.5

Expansion license to add 1 Management Server to the Enterprise System as a member of this system.

Order number **MBV-XSUB-75**



**BVMS Mobile Video Service Expansion V7.5**

Expansion license for 1 Mobile Video Service.  
Order number **MBV-XMVS-75**

**BVMS Enterprise Upgrade for Pro V7.5**

Upgrade license to expand a Professional Edition base license to an Enterprise System base license.  
Order number **MBV-FEUP-75**

**BVMS Allegiant License V7.5**

Expansion license to connect 1 Allegiant Matrix to a Management Server.  
Order number **MBV-FALG-75**

**BVMS POS/ATM License V7.5**

Expansion license to integrate ATM/POS devices.  
Order number **MBV-FATM-75**

**BVMS OPC Server License V7.5**

Expansion license to integrate a Building Integration System (BIS).  
Order number **MBV-FOPC-75**

**BVMS Failover VRM channel expansion V7.5**

Expansion license for 1 encoder channel used with a Failover VRM.  
Order number **MBV-XFOV-75**

**BVMS Dual Recording VRM channel expansion V7.5**

Expansion license for 1 encoder channel used for dual recording.  
Order number **MBV-XDUR-75**

**BVMS Intrusion Panel Expansion V7.5**

Expansion license to integrate intrusion panels.  
Order number **MBV-XINT-75**

**BVMS Site Expansion V7.5**

Expansion license for 1 site. Order the exact number required.  
Order number **MBV-XSITE-75**

**BVMS Plus Edition V7.5**

Base license for Plus Edition. 64 cameras (max 256); 5 workstations (max 10); 5 CCTV keyboards (max 10); All Plus Edition MBV-X\* and MBV-F\* options are only available with Base license.  
Order number **MBV-BPLU-75**

**BVMS Plus Channel (Enc/Dec) Expansion V7.5**

Expansion license for 1 encoder/decoder channel. Order the exact number required. Maximum 64 (included in base package) + 192 for Plus Edition.  
Order number **MBV-XCHANPLU-75**

**BVMS Plus Workstation Expansion V7.5**

Expansion license for 1 workstation (each extra workstation requires 1 license). Maximum 5 (included in base package) + 5 for Plus Edition.  
Order number **MBV-XWSTPLU-75**

**BVMS Plus DVR Expansion V7.5**

Expansion license for 1 DVR. Order the exact number required. Maximum 5 for Plus Edition.  
Order number **MBV-XDVRPLU-75**

**BVMS Plus CCTV Keyboard Expansion V7.5**

Expansion license for 1 CCTV keyboard. Order the exact number required. Maximum 5 (included in base package) + 5 for Plus Edition.  
Order number **MBV-XKBDPLU-75**

**BVMS Plus Mobile Video Service Expansion V7.5**

Expansion license for 1 Mobile Video Service.  
Order number **MBV-XMVSPLU-75**

**BVMS Plus Failover VRM Channel Expansion V7.5**

Expansion license for 1 encoder channel used with a Failover VRM. Maximum 256 for Plus Edition. Maximum 2 VRMs can be used.  
Order number **MBV-XFOVPLU-75**

**BVMS Plus Dual Recording VRM Channel Expansion V7.5**

Expansion license for 1 encoder channel used for dual recording. Maximum 256 for Plus Edition. Maximum 2 VRMs can be used.  
Order number **MBV-XDURPLU-75**

**BVMS Plus Intrusion Panel Expansion Plus V7.5**

Expansion license to integrate intrusion panels. Maximum 10 for Plus Edition.  
Order number **MBV-XINTPLU-75**

**KBD-Universal XF**

USB CCTV-oriented keyboard for use with Bosch Video Management System, BIS - Video Engine, or DIVAR IP systems.  
Order number **KBD-UXF**

**Maintenance Server Lookup**

One year of maintenance cover for the Server Lookup expansion license  
Order number **MBV-MSRVL-45**

**Bosch VMS Upgrade BLITE64 to BPro w. 64 channels**

License to upgrade an installed Lite-64 Edition to a Professional Edition with 64 channels. **Always** include the computer hardware ID of installed Lite-64 system with the order.  
Order number **BVMS-LITEPRO-64**

**Bosch VMS Upgrade BLITE32 to BPro w. 32 channels**

License to upgrade an installed Lite-32 Edition to a Professional Edition with 32 channels. **Always** include the computer hardware ID of installed Lite-32 system with the order.  
Order number **BVMS-LITEPRO-32**

**Integration of 1 ONVIF compliant camera**

Service to integrate 1 ONVIF compliant camera with Bosch VMS. Terms and Conditions see Bosch Integration Partner Program website.  
Order number **MBV-3RD-PRTY**

**Maintenance Lite-32-Edition**

One year of maintenance cover for the Lite-32 license.  
Order number **MBV-MLIT32**

---

**Maintenance Lite-64-Edition**

One year of maintenance cover for the Lite-64 license.  
Order number **MBV-MLIT64**

---

**Maintenance Professional Edition**

One year of maintenance cover for the Professional Edition base license.  
Order number **MBV-MPRO**

---

**Maintenance Enterprise Edition**

One year of maintenance cover for the Enterprise Edition base license.  
Order number **MBV-MENT**

---

**Maintenance Enterprise Upgrade for Pro**

One year of maintenance cover for the upgrade license from Pro to Enterprise.  
Order number **MBV-MEUP**

---

**Maintenance Channel Expansion**

One year of maintenance cover for the channel expansion license.  
Order number **MBV-MCHAN**

---

**Maintenance DVR Expansion**

One year of maintenance cover for the DVR expansion license.  
Order number **MBV-MDVR**

---

**Maintenance Workstation Expansion**

One year of maintenance cover for the Workstation expansion license.  
Order number **MBV-MWST**

---

**Maintenance CCTV Keyboard Expansion**

One year of maintenance cover for the CCTV keyboard expansion license.  
Order number **MBV-MKBD**

---

**Maintenance Forensic Search Expansion**

One year of maintenance cover for the Forensic Search expansion license.  
Order number **MBV-MFOREN**

---

**Maintenance Enterprise Subsystem**

One year of maintenance cover for an Enterprise Subsystem expansion license.  
Order number **MBV-MSUB**

---

**Maintenance Mobile Video Service**

One year of maintenance cover for the Mobile Video Service expansion license.  
Order number **MBV-MMVS**

---

**Maintenance Enterprise Upgrade for Pro**

One year of maintenance cover for the upgrade license from Pro to Enterprise.  
Order number **MBV-MEUP**

---

**Maintenance Allegiant Matrix Connection**

One year of maintenance cover for an Allegiant Matrix expansion license.  
Order number **MBV-MALG**

---

**Maintenance ATM/POS Connection**

One year of maintenance cover for an ATM/POS expansion license.  
Order number **MBV-MATM**

---

**Maintenance Intrusion Panels**

One year of maintenance cover for an intrusion panel expansion license.  
Order number **MBV-MINT**

---

**Maintenance Site Expansion**

One year of maintenance cover for the site expansion license.  
Order number **MBV-MSITE**

---

**Maintenance OPC Server Connection**

One year of maintenance cover for the OPC Server Connection expansion license.  
Order number **MBV-MOPC**

---

**Maintenance Failover VRM**

One year of maintenance cover for a Failover VRM expansion license.  
Order number **MBV-MFOV**

---

**Maintenance Dual Recording VRM**

One year of maintenance cover for a Dual Recording VRM expansion license.  
Order number **MBV-MDUR**

---

**Maintenance Lite-32-Edition**

Three years of maintenance cover for the Lite-32 license.  
Order number **MBV-MLIT32-3YR**

---

**Maintenance Lite-64-Edition**

Three years of maintenance cover for the Lite-64 license.  
Order number **MBV-MLIT64-3YR**

---

**Maintenance Professional Edition**

Three years of maintenance cover for the Professional Edition base license.  
Order number **MBV-MPRO-3YR**

---

**Maintenance Enterprise Edition**

Three years of maintenance cover for the Enterprise Edition base license.  
Order number **MBV-MENT-3YR**

---

**Maintenance Enterprise Upgrade for Pro**

Three years of maintenance cover for the upgrade license from Pro to Enterprise.  
Order number **MBV-MEUP-3YR**

---

**Maintenance Channel Expansion**

Three years of maintenance cover for the channel expansion license.  
Order number **MBV-MCHAN-3YR**

---

**Maintenance DVR Expansion**

Three years of maintenance cover for the DVR expansion license.

Order number **MBV-MDVR-3YR**

**Maintenance Workstation Expansion**

Three years of maintenance cover for the Workstation expansion license.

Order number **MBV-MWST-3YR**

**Maintenance CCTV Keyboard Expansion**

Three years of maintenance cover for the CCTV keyboard expansion license.

Order number **MBV-MKBD-3YR**

**Maintenance Forensic Search Expansion**

Three years of maintenance cover for the Forensic Search expansion license.

Order number **MBV-MFOREN-3YR**

**Maintenance Subsystem**

Three years of maintenance cover for a Subsystem expansion license.

Order number **MBV-MSUB-3YR**

**Maintenance Mobile Video Service**

Three years of maintenance cover for the Mobile Video Service expansion license.

Order number **MBV-MMVS-3YR**

**Maintenance Allegiant Matrix Connection**

Three years of maintenance cover for an Allegiant Matrix expansion license.

Order number **MBV-MALG-3YR**

**Maintenance ATM/POS Connection**

Three years of maintenance cover for an ATM/POS expansion license.

Order number **MBV-MATM-3YR**

**Maintenance Intrusion Panels**

Three years of maintenance cover for an intrusion panel expansion license.

Order number **MBV-MINT-3YR**

**Maintenance Site Expansion**

Three years of maintenance cover for the site expansion license.

Order number **MBV-MSITE-3YR**

**Maintenance OPC Server Connection**

Three years of maintenance cover for the OPC Server Connection expansion license.

Order number **MBV-MOPC-3YR**

**Maintenance Failover VRM**

Three years of maintenance cover for a Failover VRM expansion license.

Order number **MBV-MFOV-3YR**

**Maintenance Dual Recording VRM**

Three years of maintenance cover for a Dual Recording VRM expansion license.

Order number **MBV-MDUR-3YR**

**Bosch VMS Plus Edition SMA Ext 1yr (e-license)**

1 year of maintenance cover for the Plus Edition base license.

Order number **MBV-MPLU**

**Bosch VMS Channel Exp SMA Ext 1yr (e-license)**

1 year of maintenance cover for the Plus Edition channel expansion license.

Order number **MBV-MCHANPLU**

**Bosch VMS Workstation Exp SMA Ext 1yr (e-license)**

1 year of maintenance cover for the Plus Edition workstation expansion license.

Order number **MBV-MWSTPLU**

**Bosch VMS Forensic Exp SMA Ext 1yr (e-license)**

1 year of maintenance cover for the Plus Edition Forensic Search expansion license.

Order number **MBV-MFORENPLU**

**Bosch VMS DVR Exp SMA Ext 1yr (e-license)**

1 year of maintenance cover for the Plus Edition DVR expansion license.

Order number **MBV-MDVRPLU**

**Bosch VMS CCTV Keyboard Exp SMA Ext 1yr (e-license)**

1 year of maintenance cover for the Plus Edition CCTV keyboard expansion license.

Order number **MBV-MKBDPLU**

**Bosch VMS MVS Exp SMA Ext 1yr (e-license)**

1 year of maintenance cover for the Plus Edition MVS expansion license.

Order number **MBV-MMVSPLU**

**Bosch VMS Failover VRM Exp (1Ch) SMA Ext 1yr**

1 year of maintenance cover for the Plus Edition Failover VRM expansion license.

Order number **MBV-MFOVPLU**

**Bosch VMS Dual R. VRM Exp (1Ch) SMA Ext 1yr**

1 year of maintenance cover for the Plus Edition Dual Recording VRM expansion license.

Order number **MBV-MDURPLU**

**Bosch VMS Intrusion Panel Exp SMA Ext 1yr**

1 year of maintenance cover for a Plus Edition intrusion panel expansion license.

Order number **MBV-MINTPLU-3YR**

**Bosch VMS Plus Edition SMA Ext 3yr (e-license)**

3 years of maintenance cover for the Plus Edition base license.

Order number **MBV-MPLU-3YR**

**Bosch VMS Channel Exp SMA Ext 3yr (e-license)**

3 year of maintenance cover for the Plus Edition channel expansion license.

Order number **MBV-MCHANPLU-3YR**

**Bosch VMS Workstation Exp SMA Ext 3yr (e-license)**

3 years of maintenance cover for the Plus Edition workstation expansion license.

Order number **MBV-MWSTPLU-3YR**

**Bosch VMS Forensic Exp SMA Ext 3yr (e-license)**

3 years of maintenance cover for the Plus Edition Forensic Search expansion license.  
Order number **MBV-MFORENPLU-3YR**

---

**Bosch VMS DVR Exp SMA Ext 3yr (e-license)**

3 years of maintenance cover for the Plus Edition DVR expansion license.  
Order number **MBV-MDVRPLU-3YR**

---

**Bosch VMS CCTV Keyboard Exp SMA Ext 3yr (e-license)**

3 years of maintenance cover for the Plus Edition CCTV keyboard expansion license.  
Order number **MBV-MKBDPLU-3YR**

---

**Bosch VMS MVS Exp SMA Ext 3yr (e-license)**

3 years of maintenance cover for the Plus Edition MVS expansion license.  
Order number **MBV-MMVSPLU-3YR**

---

**Bosch VMS Failover VRM Exp (1Ch) SMA Ext 3yr**

3 years of maintenance cover for the Plus Edition Failover VRM expansion license.  
Order number **MBV-MFOVPLU-3YR**

---

**Bosch VMS Dual R. VRM Exp (1Ch) SMA Ext 3yr**

3 years of maintenance cover for the Plus Edition Dual Recording VRM expansion license.  
Order number **MBV-MDURPLU-3YR**

---

**Bosch VMS Intrusion Panel Exp SMA Ext 3yr**

3 years of maintenance cover for a Plus Edition intrusion panel expansion license.  
Order number **MBV-MINTPLU-3YR**

---

**Represented by:**

**Europe, Middle East, Africa:**

Bosch Security Systems B.V.  
P.O. Box 80002  
5600 JB Eindhoven, The Netherlands  
Phone: + 31 40 2577 284  
emea.securitysystems@bosch.com  
emea.boschsecurity.com

**Germany:**

Bosch Sicherheitssysteme GmbH  
Robert-Bosch-Ring 5  
85630 Grasbrunn  
Germany  
www.boschsecurity.com

**North America:**

Bosch Security Systems, Inc.  
130 Perinton Parkway  
Fairport, New York, 14450, USA  
Phone: +1 800 289 0096  
Fax: +1 585 223 9180  
onlinehelp@us.bosch.com  
www.boschsecurity.us

**Asia-Pacific:**

Robert Bosch (SEA) Pte Ltd, Security Systems  
11 Bishan Street 21  
Singapore 573943  
Phone: +65 6571 2808  
Fax: +65 6571 2699  
apr.securitysystems@bosch.com  
www.boschsecurity.asia